



- 4: Mount the follower panels by sliding them over the bolts, carrying- and guiding bar. Close the latches.

  5: Mount the flexible insulation inserts to the bolts and bottom of the follower panels. Ensure that the inserts are aligned with the panel surface.
- 6: Mount the first of the side panels and close the latches on the follower and side panel. 7: Mount the top panel. Do not close the latches yet.
- 8: Mount the second side panel and close the latches on the top panel with the side and follower panels.
- 9: Mount the smaller connection panels on the head side.
- 10: Mount the lower panel on the head side and slide it in place.
- 11: Mount the upper panel on the head side and close the latches.
- 12: Mount the middle panel and close the latches. Close all remaining latches.

